

Desk stand EEDK9

The desk stand EEDK9 (anodized aluminium) can be used as stand for the Duetto series versions EE 980, EE 980CM, SIP-EE 980 and SIP-EE 980CM.


Mounting

- Connect all required cables to the control station.
Note: The connection diagram of the control station is included in the short reference "D-BZ-EE980".
- Slide the control station from the top onto the desk stand into the appropriate opening of the device at the back until it locks into place. Be sure that all cables for the control desk are guided from behind between the control station and the desk stand.
- Adjust the tilt angle until the anti-twist protection of the desk stand locks into the appropriate place. A tilt angle from 68° to 28° along the horizontal plane is adjustable.

Dimensions


Dimensions in mm (in), not to scale!

Desk stand




Control station EE 980 with desk stand

max. inclination angle 68°:



min. inclination angle 28°:



Latest software and documentation

For current software and documentation visit: www.commend.com

Manufacturer's reference



The device may be only installed by authorised engineers.
Please keep this description in safe custody!

Tischhalterung EEDK9

Die Tischhalterung EEDK9 ist aus eloxiertem Aluminium gefertigt und kann als Standfuß für die Ausführungen EE 980, EE 980CM, SIP-EE 980 und SIP-EE 980CM der Duetto Serie verwendet werden.


Montage

- Schließen Sie alle benötigten Kabel an die Leitstand-Sprechstelle an.
Hinweis: Das Anschlussdiagramm der Leitstand-Sprechstelle ist im Beipackzettel „D-BZ-EE980“ enthalten.
- Schieben Sie die Leitstand-Sprechstelle von oben auf die Tischhalterung in die dafür vorgesehene Öffnung des Geräts auf der Rückseite bis es einrastet. Achten Sie darauf, dass alle Kabel von der Hinterseite zwischen der Leitstand-Sprechstelle und der Tischhalterung durchgeführt werden.
- Verstellen Sie den Neigungswinkel bis die Verdrehsicherung der Tischhalterung in der gewünschten Position einrastet. Es ist ein Neigungswinkel von 68° bis zu 28° zur horizontalen Ebene einstellbar.

Maßzeichnung


Maße in mm, kein Maßstab!

Tischhalterung




Leitstand-Sprechstelle EE 980 mit Tischhalterung

max. Neigungswinkel: 68°:



min. Neigungswinkel: 28°:



Aktuelle Software und Dokumentation

Die aktuellste Software und Dokumentation erhalten Sie unter: www.commend.com

Hinweis des Herstellers



Das Gerät darf nur von autorisiertem Fachpersonal installiert werden.
Bitte bewahren Sie diese Beschreibung sorgfältig auf!